


User instructions for insulation cups for stainless steel manifolds



⚠ Important: always wear protective gloves during all operations.

- 1. Cut the cup** according to the number of manifold outlets, making the necessary cuts for both the outbound and return branches and both on the front and back (fig. 1)
- 2. Thoroughly clean the surface of the manifolds** to remove dust, debris or impurities that could compromise adhesion.
- 3. Remove the adhesive film from the cup** (fig. 2).
- 4. Apply the cup on the manifold**, exerting slight pressure to ensure correct adhesion on the entire surface.